



# THANK YOU FOR PURCHASING AN ANVIL PRODUCT!

#### **REGISTER ONLINE TODAY**

Register your warranty on-line at www.anvilworld.com today and learn how to get the best out of your Anvil product, tips to care for your Anvil product for long lasting performance, exciting recipes and more.

## NO WEB ACCESS?

If you do not have access to the Web, register by completing this form and faxing it to the Anvil head office in South Africa. Fax: +27 11 474 1630

# ONLY COMPLETE IF YOU DO NOT HAVE WEB ACCESS

Company		
Name		
Surname		
Telephone		
Cellphone		
Email Address		
Country		
Postal address		
Anvil products purchased		
Code (see box label)		
Serial number (see back of r	machine	e)
INTENDED USE		
Full-Service restaurant		Institutional Cafeteria
Coffee Shop / Deli		Corporate Catering
Fast Food Outlet		Private Use
Hotel		Franchisor
Bed & Breakfast		Convenience Store
School Cafeteria		Other
<b>_</b> '		

### **LIMITED WARRANTY**

All equipment which is sold under ANVIL trademark and used for commercial purposes is warranted against defects in materials and workmanship. The warranty runs for two years from the date of original installation and is for the benefit of the original purchaser only. All other Warranties ,expressed or implied , statutory or otherwise, including without limitations any implied Warranty of Merchantability or fitness for purpose are excluded .The Seller shall in no event be liable for direct,indirect or consequential damages in connection with ANVIL commercial products.

The Sellers obligation under this Warranty is limited to the repair of defects without charge. Defective units must be taken or shipped, transportation charges prepaid, to ANVIL.

This Warranty is not effective if damage occurs because of accident, carelessness, improper installation, lack of proper set-up, supervision when required or if the equipment is installed or operated in any manner contrary to the installation and operating instructions. In these cases, repairs will be made at a reasonable cost. Work performed by unauthorized personnel or unauthorized service agencies using non Anvil spares voids this Warranty.




## **REGISTER ON-LINE TODAY**

Register your warranty on-line now at www.anvilworld.com

# **NO WEB ACCESS**

If you do not have access to the Web. Kindly register by completing the warranty registration form and fax it to the ANVIL office in the country of purchase.

Failure to do so will invalidate your warranty.



INSTALLATION OPERATION AND CARE OF REFRIGERATED DISPLAY CABINETS MODEL: DFC0900,DFC1200,DFC1500 DFC5900,DFC5200,DFC5500 DFC7900,DFC7200,DFC7500,DFC8200

Unpack the product and check for any damage incurred during transit. This should be reported to the responsible carrier, railway or postal authority, and a request for a damage report should be made.




THESE INSTRUCTIONS MUST BE FOLLOWED FOR US TO GUARANTEE OUR FULL SUPPORT OF YOUR CLAIM FOR PROTECTING AGAINST LOSS FROM CONCEALED DAMAGE. THE FORM FOR FILING SUCH A CLAIM WILL BE PROVIDED BY THE CARRIER.

## **GENERAL INSTALLATION AND OPERATION INSTRUCTIONS:**


The ANVIL Refrigerated Display cabinets are designed for illuminated display of food products at temperatures between  $+2^{\circ} + 8^{\circ}$  C. The cooling system ensures that the products placed inside can be stored at the correct temperature.


- 1. IF THE UNIT HAS BEEN TRANSPORTED IN A NON-VERTICAL POSITION ALLOW AT LEAST 1 HOUR FOR THE FOR THE OIL TO FLOW BACK INTO THE COMPRESSOR AFTER FINAL INSTALLATION BEFORE SWITCHING ON
- 2. Assemble the shelving system and rear doors.
- 3. Remove all the protective film from exposed stainless steel parts and surfaces.
- 3. The unit is designed for food display. Clean carefully before using by following the specific cleaning instructions detailed later in this manual.
- 4. Plug the unit into a suitable power source as detailed later in this manual.
- 5. The unit is provided with a digital control panel for switching on and off as well as temperature setting. See the operating instruction on page 2 for details.
- 6. The interior lights can be operated by using the lighting button located below the digital control.



PRODUCT CODE	A	В	၁
DFC7900	900mm (36')	680 (26,77")	1200 (47.24")
DFC7200	1200mm (48")	680 (26,77")	1200 (47.24")
DFC7500	1500mm (60")	680 (26,77")	1200 (47.24")
DFC8200	1200mm (48")	680 (26,77")	1200 (47.24")









Dimensions mm (inches)


### **SPECIFIC OPERATING INSTRUCTIONS**


The following are the specific operating instructions to set the temperature controller. It is advisable not to reset the controller frequently.




- 1. Press the button for 3 seconds to switch on the controller.
- 2. To set the temperature, press of for 1 second. The numerals will flash on the display. Adjust the temperature value up or down using the arrow buttons, the value will be stored automatically after 6 seconds.
- 3. The unit will start cooling after 3 minutes. The range is effective from +2°C to 20°C.
- 4. The unit has a preset defrost cycle of every 6 hrs for a 20 minute duration.
- 5. Manual defrosting can be initiated by pressing the arrow for 3 seconds. The defrost symbol will illuminate on the digital display. The defrost mode can be exited by pressing the arrow for 3 seconds.










# **CONTROL PANEL Cont.**

- Manual window demisting can be initiated by pressing the <u>\vec{\text{\tint{\text{\tint{\text{\tilitet{\text{\tilitt{\text{\t</u>
- 7. The lights may be switched on or off by the touch sensitive switch marked -
- 8. To switch off the unit, press and hold the button for 3 seconds.

#### **CLEANING**

- 1) It is advisable to clean the interior of the machine as often as possible to maintain good hygiene standards.
- 2) Always ensure that the unit is disconnected from the main power supply before cleaning.
- 3) Do not use abrasive powders or solvents to clean this unit.
- 4) The unit should be cleaned with warm soapy water. Use only a damp cloth.
- 5) Dry the unit carefully with a cloth before turning back on.
- 6) IT IS ESSENTIAL THAT THE COOLING CONDENSER AND FILTER IS CLEANED ON A REGULAR BASIS TO ENSURE OPTIMUM PERFORMANCE OF THE UNIT.
  THE CONDENSER IS ACCESSIBLE BY REMOVING THE PANEL ADJACENT TO THE CONTROLLER. SEE INSTRUCTIONS ON THE REAR OF THE UNIT.
  CLEAN CAREFULLY WITH A SUITABLE SOFT BRUSH OR COMPRESSED AIR IF POSSIBLE.

THE UNIT SHOULD NEVER BE CLEANED USING A WATER JET OR SIMILAR PRESSURE CLEANING DEVICE.



# WIRING DIAGRAM LEGEND DISPLAY UNITS REFRIGERATED

LEGEND	DESCRIPTION
SH1	ON/OFF LIGHT SWITCH
Mn	CIRCULATION FAN EVAPORATOR
М3	CIRCULATION FAN EVAPORATOR
M2	CONDENSER FAN MOTOR
M1	COMPRESSOR
EH1	GLASS HEATER ELEMENT
EH2	DOOR GLASS HEATER ELEMENT
RK325	TEMPERATURE CONTROLLER
RT2	DEFROST SENSOR
RT1	TEMPERATURE SENSOR
EL	LED LIGHTS
FA	OVERLOAD PROTECTOR
T1	TRANSFORMER
TC	AC/DC TRANSFORMER
EL1	SWITCH LAMP
МВ	CONTROL PANEL



# **⚠** WARNING

### **Electric Shock Hazard.**

Keep water and other liquids from entering the inside of the equipment. Liquid inside the equipment could cause an electrical shock

Do not spray water or cleaning products. Liquid could contact the electrical components and cause a short circuit or an electrical shock. Do not use equipment if power cord is damaged or has been modified

#### **SAFETY**

7

# READ ALL INSTRUCTIONS BEFORE USE. FAILURE TO FOLLOW THESE PRECAUTIONS COULD RESULT IN INJURY TO YOURSELF AND OTHERS

- 1. The units are designed to operate on alternating current only (A.C.). DO NOT CONNECT TO DIRECT CURRENT (D.C.).
- 2. Ensure that the power supply cord does not come into contact with hot surfaces.
- 3. If the supply cord is damaged, it must be replaced with a new cord assembly available from the suppliers agent.
- 4. Do not use the unit in a dusty environment or in and explosive atmosphere.
- 5. This unit is designed for indoor use only
- 6. BASIC SAFETY RULES
  - a. Do not touch the unit when hands and feet are wet
  - b. Do not use the unit when bare foot
  - c. The unit should never be used by children or untrained personnel
  - d. Do not pull on the electrical cord when unplugging the machine.

# **DESCRIPTION OF MODELS**

MODEL	DESCRIPTION	CAPACITY	VOLTAGE ( V/Hz)	POWER ( WATTS)
DFC0900	DELI FRIDGE 900mm	225L	230/50	580
DFC1200	DELI FRIDGE 1200mm	310L	230/50	705
DFC1500	DELI FRIDGE 1500mm	395L	230/50	855
DFC5900	DELI FRIDGE 900mm	285L	230/50	626
DFC5200	DELI FRIDGE 1200mm	390L	230/50	773
DFC5500	DELI FRIDGE 1500mm	500L	230/50	931
DFC7900	DELI FRIDGE 900mm	285L	230/50	626
DFC7200	DELI FRIDGE 1200mm	390L	230/50	769
DFC7500	DELI FRIDGE 1500mm	500L	230/50	923
DFC8200	DELI FRIDGE 1200mm	390L	230/50	769

# WIRING DIAGRAM DISPLAY UNITS REFRIGERATED

